

LTE TDD from A-Z

Table of Content:

1 Differences between LTE-FDD and LTE-TDD

- **TDD Portions in major 3GPP LTE Specifications**
- **Introduction to LTE TDD**
 - ⇒ LTE Key Parameters for FDD and TDD
 - ⇒ Why LTE-TDD? Why variable Downlink-Uplink Subframes?
- **UE LTE Categories for FDD & TDD**
 - Time / Frequency View on OFDM: The "Grid", Subcarrier Spacing in LTE, Transmission Bandwidth in LTE, LTE specific OFDM/FFT and Subcarrier Parameters
 - ⇒ Downlink Reference Signals (Pilot) - Common Reference Signals
RSRP and RSRQ
 - ⇒ Categorization of Smart Antenna's
- **DL Transmission Modes & DL Control Information**
 - Principle Operation of Closed Loop
 - ⇒ Channel Quality Indicator (CQI) definition
 - ⇒ Introduction to Spatial Multiplexing – N x TX & N x RX
- **The Frequency Bands for LTE, UMTS & GSM – Rel. 10**
 - ⇒ Frequency Distribution among Operators in Germany
 - ⇒ E-UTRAN Channel Bandwidth (Rel. 10)
E-ARFCN of TDD up to Rel. 10 (3GPP TS 36.101 V10.6.0 (2012-03))
- **Basic Layer 1 Details of TDD**
 - ⇒ UL/DL Configurations of LTE-TDD
Frames in LTE
 - ⇒ Example UL-DL Subframe Configuration 0 & Special Subframe S
The Special Subframe, Downlink Pilot Timeslot (DwPTS), Uplink Pilot Timeslot (UpPTS)
 - ⇒ TD-LTE and LTE FDD Differences - Part1
TD-LTE Coverage
 - ⇒ TD-LTE and LTE FDD Differences – Part 2
 - ⇒ Purpose of the Special Subframe S in LTE-TDD
DwPTS, GP and UpPTS Fields

- ⇒ Transmission Timing Adjustments & Timing Advance Offset
Timing Advance and the Purpose of Guard Period GP, The Guard Period
- ⇒ LTE-TDD Random Access Channels
Preamble Formats 0 and 4 in Comparison, The S-RACH, Details of PRACH Format #4 in UpPTS, Basic PRACH Random Access Procedure, Multiple RACH in the Frequency Domain
- ⇒ Sounding Reference Signals - SRS
- ⇒ Sounding Procedure – SRS uplink Transmission (FDD)
- ⇒ Mapping of Channels in E-UTRAN- same for FDD and TDD
- ⇒ Time Frequency Grid for DL OFDMA & UL SC-FDMA
DL Resource Element, Resource Block & UL RB Structure
- ⇒ UL & DL Time-Frequency Grid - Draft
Uplink Demodulation Reference Signals, Uplink Sounding Reference Signals (SRS), Uplink Layer 1/Layer 2 Control Signaling on PUCCH, Physical Uplink Shared Channel (PUSCH)
- ⇒ PUCCH & UCI (Uplink Control Indicator) – UL Control Signaling
PUCCH Format 1, 1a and 1b, PUCCH Format 2, 2a and 2b – Uplink Control Signaling , PUSCH taking over Control Signaling, Information transferred by each PUCCH Format, Primary and Secondary Sync Signals – FDD vs. TDD , Details on Primary Synchronization Signal (PSS) Sequences, Details on Secondary Synchronization Signal (SSS) Sequences, Cell Search Performance
- **Physical Cell ID derived by PSS+SSS**
Content and Periodicity of the PBCH, Note to Rel. 10 (LTE Advanced)
 - ⇒ Cell Search Procedure in LTE
SSS Detection in LTE – Four Possibilities, Synchronization Sequences and Cell Search in LTE, Secondary Synchronization Signal (SSS) Sequences, Antenna Ports and their associated Reference Signals
- **TD-LTE Beamforming**
 - ⇒ Introduction to Transmission Mode 7 (Rel. 8)
 - ⇒ UE Specific Reference Signals
Port 5 and MBMS, Antenna Port 7 and 8 (from Rel. 9 onwards)
 - ⇒ Dual Layer Beamforming – Transmission 8 and 9
 - ⇒ TD-SCDMA and TD-LTE
- **Resource Allocation and HARQ**
 - ⇒ Downlink Resource Allocation in FDD
Uplink Resource Allocation in FDD, FDD HARQ versus TDD HARQ & ACK-NACK Timing
 - ⇒ DL and UL maximum HARQ Processes per Subframe Assignment
 - ⇒ Downlink Resource Allocation
Multiple HARQ-ACK/NACK in uplink for sa1 to sa6, Downlink Assignment Index
 - ⇒ UL Resource Allocation
- **Other Features**
 - ⇒ UL TTI bundling
 - ⇒ Semi Persistent Scheduling in TD-LTE

⇒ Sounding Reference Signals (SRS) in TD-LTE